

Dartmouth & Carrollton Trip Lever Installation - THU141

1. Place Rubber Washer onto Escutcheon.
2. Place Escutcheon into tank square hole. The U-channel opening should point to 10 o'clock and 6 o'clock positions.
3. Slide Brass Washer onto Escutcheon's thread.
4. Place Brass nut counter-clockwise onto Escutcheon's thread. Tighten securely.
5. Insert Brass Rod into Escutcheon's U-channel. Rod's bend should point downward to the 6 o'clock position.
6. Place Handle onto Brass Rod's splined shaft. Handle should point downward to the 6 o'clock position. Push Handle and Brass Rod together to seat.
7. Place a drop of thread locker (not supplied) onto #2 Screw thread near thread's end. Attach #2 Screw to Handle and then tighten securely.

NOTE: Suggested thread locker LOCTITE 241.

